

REPLACEMENT TRANSMITTERS



X11RF-LCD

2-Way LCD Transmitter X11RF-LCD

- Replacement transmitter with black case and key chain for X11.



X11RF

4-Button Transmitter X11RF

- Replacement transmitter with black case and key chain for X11.



X4RF-LCD

2-Way LCD Transmitter X4RF-LCD

- Replacement transmitter with black case and key chain for X4 and X9.



X7RF

5-Button Transmitter X7RF

- Replacement transmitter with black case and key chain for X3, X4, X6, X7 and X9.



M12ARF-LCD

2-Way LCD Transmitter M12ARF-LCD

- Replacement transmitter with black case and key chain for M11A-1 and M12a.



M11RF-LCD

2-Way Transmitter M11RF-LCD (Pre-coded)

- Replacement transmitter with black case and key chain for M11 and M11a.



M11RF

4-Button Transmitter M11RF (Pre-coded)

- Replacement transmitter with black case and key chain for M11 and M11a.



M9ARF-LCD

2-Way LCD Transmitter M9ARF-LCD

- Replacement transmitter with black case and key chain for M9a.

2-Way LED Transmitter M8ARF-LED

- Replacement transmitter with black case and key chain for M8a and M5A2WP.



M8ARF-LED

5-Button Transmitter M5ARF (2-Car Option)

- Replacement transmitter with black case and key chain for M4, M4a, M5, M5a, M6a, M7, M7a and M8a.



M5ARF

3-Button Transmitter M3ARF

- Replacement transmitter with black case and key chain for M3 and M3a.



M3ARF

3-Button Transmitter MCRF3CD (Code Hopping)

- Replacement transmitter with gray case and key chain for MCD55C, MC44, MC45H and MC55.



MCRF3CD

3-Button Transmitter M3RF-3 (Code Hopping)

- Replacement transmitter with black case and key chain for M3.



M3RF-3

4-Button Transmitter SA-RF4 (Pre-coded)

- Replacement transmitter with gray case and key chain for S215, S315, S415, S515 and S615.



SA-RF4

2-Button Transmitter SA-RF2C (Pre-coded)

- Replacement transmitter with black case and key chain for S312, S412, S457, S557 and S657.



SA-RF2C

REPLACEMENT TRANSMITTER BATTERIES



ALA-BATT/P

12 Volt ALA-BATT/P

- For most RF transmitters.
- 5 batteries per card.

PK. 5 WT. 1

3 Volt Lithium CR2032

- For X11RF, X4ARF, M11RF, M5ARF and M3ARF.
- 5 batteries per card.

PK. 5 WT. 1



CR2032

3 Volt Lithium ALABATT2450

- For M8ARF-LED.
- 5 batteries per card.

PK. 5 WT. 1



ALABATT2450